





Connect the '**BRI**' pad of the Ribbon cable to the '**Q128**' pad of the mainboard of the console by a wire.



