

In order to output the game to the TV set please remove the resistor on the "EM3"

After remove the 'EM3'



1.Apply the insulating film on the metal surface.









Connect "AV" pad of the black backlight PCB to the "Pin 1" pad of the mainboard of the console by a wire

Connect "G" pad of the black backlight PCB to the "GND" pad of the mainboard of the console by a wire.









## Connect SEL to the TP2, please check this picture.







